

Technical Data Sheet

Product:

PN# CP-GK3-9025

2.3-MIL-WHT-OPP-T/C-METALBACKSIDE-99-1.2PET

Description:

A 2.3mil white, metalized polypropylene featuring 99 permanent adhesive and 1.2mil clear polyester liner.

Recommended Applications:

- Block-out labels
- Opaque cover-up

The metalized side of the film demonstrates a highly reflective surface. The OPP side has greater light diffusion, but also features a reflective surface.

99 adhesive features excellent adhesion to low surface energy substrates, as well as resistance to moisture and solvents.

Facestock:

2.3mil white metalized BOPP

		<u>Value</u>	<u>Units</u>	<u>ASTM Method</u>
Caliper:		2.3	mils	
Tensile:	MD	26.1	kpsi	D-882
	TD	21.75	kpsi	D-882
Elongation:	MD	85	percent	D-882
	TD	110	percent	D-882
Metal Density:		2.5-2.9	OD	

Adhesive:

99 permanent

	<u>Value</u>	<u>Units</u>	<u>ASTM Method</u>
Loop Tack:	5.3	lbs/in ²	PSTC-16(SS)
Peel Adhesion			
20 minute:	4	lbs/in	PSTC-101(SS)
24 hour:	5	lbs/in	PSTC-101(SS)
20 minute:	1.75	lbs/in	PSTC-101(HDPE)
24 hour:	2.2	lbs/in	PSTC-101(HDPE)
Shear Adhesion:	Medium		PSTC-107(SS)
(1"x1"x1000gm)			

Minimum Application Temperature: 50°F

Service Temperature Range: -40°F to +248°F

General Data Coated Products

4354 Ferguson Drive • Cincinnati, Ohio 45245 • Phone: 800-733-5252 x2374 • Fax: 513-752-6947

Email: solutions@general-data.com • Web: <http://www.general-data.com>

MADE IN THE USA



Technical Data Sheet

Liner:

1.2mil clear PET

		<u>Value</u>	<u>Units</u>	<u>ASTM Method</u>
Caliper:		1.2	mil	
Tensile:	MD	>19	Kg/mm ²	D882
	TD	>19	Kg/mm ²	D882
Elongation at Break:	MD	60-150	percent	D882
	TD	60-150	percent	D882
Shrinkage:	MD	.6-2.5	percent	MI-25 (150°C-30')
	TD	0-1.2	percent	MI-25 (150°C-30')

Shelf Life:

One year under standard storage and humidity conditions. For maximum product longevity, store out of direct sunlight.

For product inquiries, please contact:
Paula Becknell
Sales Coordinator
800-733-5252 ext. 2374
pbecknell@general-data.com

Note: Values on this page are nominal – subject to normal industry variance.

PRODUCT DISCLAIMER

All labels and label material constructions are sold with the understanding that the purchaser has independently determined the suitability of each product for the application for which it is purchased. The seller disclaims any implied warranty of fitness of a product for a particular purpose. All materials should be tested thoroughly by the purchaser under end-use conditions to ensure they meet the requirements of a specific application.

General Data Coated Products

4354 Ferguson Drive • Cincinnati, Ohio 45245 • Phone: 800-733-5252 x2374 • Fax: 513-752-6947
Email: solutions@general-data.com • Web: <http://www.general-data.com>

MADE IN THE USA

