

## Black Rhino™ Stock Labels & Tags

- Black Rhino™ Preferred
- Black Rhino™ Value
- Black Rhino™ ThinTek™
- Black Rhino™ Small Core
- **BLACK RHINO™ LINERLESS**
- Black Rhino™ SmartLaser
- G-Band™ Wristbands
- Black Rhino™ Thermal Transfer Ribbons

General Data's line of Black Rhino™ Linerless Stock Labels are pressure-sensitive labels that do not have a liner. A special release coating is applied to the face of the label which allows the labels to be wound on a roll without the adhesive sticking to the label below it. Eliminating the liner allows for 60% more labels on each roll versus standard lined labels. This is a smarter and greener solution by reducing solid waste stream and eliminating silicone in landfills.



### Facestock

	Description	Caliper
Direct Thermal Topcoated Labels	Bright white ultra smooth paper facestock with special topcoat	3.8 - 4.1 mil

### Adhesive

	Minimum Application Temperature	Service Temperature Range
Hot Melt Permanent Adhesive	+35°F	0° to +140°F

#### PRODUCT DISCLAIMER

All labels and label material constructions are sold with the understanding that the purchaser has independently determined the suitability of each product for the application for which it is purchased. The seller disclaims any implied warranty of fitness of a product for a particular purpose. All materials should be tested thoroughly by the purchaser under end-user conditions to ensure they meet the requirements of a specific application.