

Clear View Window & Door Labels

Highly Durable, Easy to Apply Window & Door Labels With No Sticky Residue Left Behind



Clear View Window & Door Labels are specifically designed for application to windows or other glass surfaces. Include product information, instructions, consumer information, certifications, and full color brand logos all on a high-performance window label that can be easily removed months after application without leaving behind sticky adhesive residue on the window's surface.

Clear View Window & Door Labels are available in paper and film substrates, with a liner and also in a linerless construction that allows for easy application and no waste.

- **Choice Of Durable Film or Economical Paper Materials**

Film-based option resists abrasion, tearing and other damage, while paper option is an economical solution for short-term indoor use

- **Ultra-Removeable Adhesive**

Easy to apply and re-position, leaves no adhesive residue when removed

- **Zero Waste With The Linerless Option**

The linerless option means there is no liner to remove and dispose of in landfills

- **Customize To Your Needs**

Can be pre-printed both sides with text, barcodes, graphics and logos



Clear View Window & Door Labels

SPECIFICATIONS

	Paper Option (linerless)	Film Option (linerless)	Film Option (with liner)
Facestock			
Type:	50# C1S semi-gloss paper	3 mil white cavitated polyester film	3 mil white cavitated polyester film
Tensile Strength:	MD 35 MPa TD 17 MPa	MD 127 MPa TD 155 MPa	MD 127 MPa TD 155 MPa
Caliper:	2.9 mil	2.95 mil	2.95 mil
Gloss:	72.0 (75°)	15.3%	15.3%

Adhesive

Type:	Low tack removable adhesive	Low tack removable adhesive	Low tack removable adhesive
Application Temp:	Minimum 10°F	Minimum 10°F	Minimum 40°F
Service Temp:	20°F to 250°F	-40°F to 250°F	0°F to 120°F

Liner

Type:	N/A	N/A	40# SCK silicone coated one side
Caliper:	N/A	N/A	2.5 mil

Notes

- Shelf life is 6 months from purchase, when stored in closed original cartons, indoors in a climate-controlled environment.
- Clear View window & door labels should only be applied to the inside of the glass window. Do not apply to outside of glass window where label can be exposed to rain or other elements.
- Clear View window & door labels can be pre-printed on both sides of the label up to 5 colors total. The film option with liner can be variably printed on-demand with thermal transfer or special laser printers. Linerless versions are not recommended for variable or on-demand printing with thermal, laser or inkjet printers.