

# HONEYWELL 8675i

## Rugged Compact Wearable Scanner

**The Honeywell 8675i provides wearable scanning productivity in a compact, ergonomic, and rugged form factor.**

The 8675i offers always-at-hand wearable scanning to improve workflow productivity. Premium scanning performance ensures quick work of even damaged or low quality barcodes. FlexRange™ technology provides expanded FlexRange™ scan distance, enabling improved efficiency in workflows that could previously only be solved with bulkier, heavier handheld devices. Smooth, fast reading from near to far ensures that the full range (100% UPC from near contact to 5'/1.5m, 100 mil Code 39 to 33'/10m) has fast, intuitive scanning response. A standard-range only option offers lower acquisition cost for arms-length workflows.

In all aspects of design, the 8675i has been optimized for ergonomics. Height off of the finger has been minimized to prevent interference in the work environment. All user-contact surfaces have been tailored for comfort, easy adjustment, and simple use. The triggered ring is simple to swap from right to left hand configuration, and the finger strap buckle is both easy to operate and low-profile to prevent interference between fingers. The 8675i can be converted from ring to glove instantly and with no tools; the strap glove is simple, minimal, and easily adjustable to cover the range of users. Made of non-absorbent materials, the 8675i scanner and triggered ring wearable accessories are simple to clean with approved disinfectant agents.

The 8675i has been designed to satisfy the needs of demanding workflows. It is multi-shift ready, with an easy-to-replace battery to keep the scanner up and running that also enables the battery to be simply replaced as it ages through normal use, extending the service life of the 8675i. User-facing LEDs communicate Bluetooth connection, battery state of charge and even when battery health requires a replacement.



*The 8675i rugged compact wearable scanner provides ergonomic, high performance scanning. Designed to deliver reliable results in demanding workflows, this productivity tool is ready to perform in real-world applications.*

Robust 2,000 x 1/2 meter tumble specification ensures that 8675i is ready to endure the frequent knocks that wearable devices in fast-paced environments often experience. IP65 sealing and broad operating temperatures (-20° to 50°C, -4° to 122°F) ensure unconditioned warehouses, frozen environments are no problem for the 8675i. New outdoor aiming guides provide accurate barcode targeting even in full daylight when laser aimers cannot be seen. And Operational Intelligence makes configuring, monitoring, and managing deployed devices simple.

## FEATURES AND BENEFITS



Improve productivity with premium scanning performance including workflow-enabling FlexRange™ scan distance.



Reduce barriers to adoption with lightweight, comfortable, highly ergonomic form factors.



Satisfy operational challenges with a wearable expressly designed for demanding workflows.



Multi-shift ready, with an easily removable smart battery to improve ROI and maximize device lifespan.



Easily monitor and manage a fleet of deployed 8675i devices with Operational Intelligence.

# 8675i Rugged Compact Scanner Technical Specifications

## MECHANICAL

### Dimensions (L x W x H):

65.2 mm x 30.3mm x 15.2mm  
(2.6 in x 1.2 in x 0.6in)

### Weight:

#### Triggered ring with battery:

8675i-SR 63g (2.3 oz)

8675i-FR 66g (2.4 oz)

#### Scanner module without wearable accessory or battery:

8675i-SR 50g (1.8 oz)

8675i-FR 53g (1.9 oz)

### Scan performance:

#### Scan Pattern:

Omni-directional area imager

#### Symbol Contrast:

20% minimum reflectance

#### Pitch: +/-60°

#### Skew: +/-60°

### Warranty: Two-year factory warranty

(Note: Battery warranty is one year)

## WIRELESS

### Radio Range:

**Bluetooth:** 2.4 GHz to 2.5GHz  
(ISM Band (Adaptive Frequency Hopping Bluetooth v5.1 Class 1; 100m (330ft) line of sight; BLE. NFC communications for simple tap-to-pair functionality.

**Battery:** 3.85V, 570mAh

### Number of scans:

12,000 over 10 hour shift

**Expected charge time:** 3.5 hours

**Battery Weight:** 19 grams (0.8 oz)

## ENVIRONMENTAL

### Operating Temperature:

**8675i-FR:**  
-20°C to 50°C (-4°F to 122°F)

**8675i-SR:**  
-20°C to 50°C (-4°F to 122°F)

### Storage Temperature:

-20°C to 60°C (-4°F to 140°F)

### Humidity:

0% to 95% relative humidity  
(non-condensing)

### Drop:

1.8m(6 ft) Mil-Std-810 Drop  
Test at operating temperature  
50x 1.5m (5 ft) to concrete  
at operating temperature

**Tumble:** 2,000 1/2 m (1.6 ft) tumbles  
per IEC 60068-2-32 specification

**Trigger:** Rated for 5MM activation cycles

**ESD:** ±15 kV Air and ±8 kV Direct

**Environmental Sealing:** Independently  
certified to meet IP65 standards for  
moisture and particle intrusion

## GLOVE CHARACTERISTICS

Strap glove securely locates 8675i on  
back of hand for optimum dexterity,  
ergonomics, and user comfort.

Highly durable design for long lifespan,  
reduced consumable costs.

Trigger rated for 5MM activation cycles.

Compatible with bare hand or conventional  
glove for comfort and user safety.

Left and right hand versions.

## WARNING

Extreme caution should be used around  
moving machinery.

For a complete listing of all compliance approvals  
and certifications, please visit

[www.honeywellaidc.com/compliance](http://www.honeywellaidc.com/compliance).

For a complete listing of all supported barcode  
symbolologies, please visit

[www.honeywellaidc.com/symbolologies](http://www.honeywellaidc.com/symbolologies).

FlexRange is a trademark or registered trademark of  
Honeywell International Inc.

Bluetooth is a trademark or registered trademark of  
Bluetooth SIG, Inc.

## TYPICAL PERFORMANCE

FLEXRANGE™ - SYMBOLOGY/ X-DIM	TYPICAL RANGE*			
8675i FR	Near mm	Near inches	Far mm	Far inches
5 mil C39	136	5.35	363	14.29
10 mil DataMatrix	150	5.91	385	15.16
10 mil C39	92	3.62	1196	47.09
13 mil UPC-A	66	2.60	1435	56.50
15 mil C128	64	2.52	1569	61.77
20 mil C39	61	2.40	2159	85.00
100 mil DataMatrix <sup>1</sup>	-	-	4503	177.28
55 mil C39 <sup>1</sup>	-	-	6544	257.64
100 mil C39 <sup>1,2</sup>	-	-	9841	387.44
8675i SR	Near mm	Near inches	Far mm	Far inches
5 mil C39	68	2.68	299	11.77
10 mil C39	38	1.50	515	20.28
20 mil C39	42	1.65	798	31.42
13 mil UPC-A	42	1.65	571	22.48
15 mil C128	40	1.57	648	25.51
10 mil DataMatrix	70	2.76	295	11.61
6.7 mil PDF417	82	3.23	242	9.53
15 mil QR Code	37	1.46	412	16.22

\*Performance may be impacted by barcode quality and environmental conditions

1. Minimum distance depends on the length of the barcode.
2. Wide to narrow ratio 3:1. Minimum code height of 3 inches.

## For more information

[sps.honeywell.com](http://sps.honeywell.com)

## Honeywell Safety and Productivity Solutions

855 S Mint St  
Charlotte, NC 28202  
800-582-4263  
[www.honeywell.com](http://www.honeywell.com)

8675i Datasheet LTR | Rev C | 11/22  
©2022 Honeywell International Inc.



**Honeywell**