

PAC5

On-Demand Full Color Print & Apply Label Applicator

The General Data PAC5 is designed specifically for use with the Epson® ColorWorks® CW-C6000P on-demand label printer with peel-and-present capabilities. When combined with this Epson printer, the PAC5 delivers an on-demand, full color print and apply labeling solution. This combination is all the more important when considering worker safety. The peel-and-present option or an automated label applicator allow for a safe and efficient workflow, even when workers are required to wear gloves.

■ Flexibility Makes Full Color Label Application Easy

The PAC5 color label print & apply solution is so easy; all the operator needs to do is place the product. And this tabletop-sized unit can print product sizes and shapes from 3x5x5" to 8x12x12", in squares, rectangles, flats, or rounds (on request).

■ Exclusive Features Allow Greater Productivity

Exclusive features such as a tamp shift and flex tamp, along with heavy-duty dual cylinder construction, allow labels to be applied to a wide variety of products. No re-set is needed on the automatic version. A 5-color light panel indicates status, and the PAC5 offers a removable printer unit and easy access to the electrical panel and pneumatics.

■ Accurate Label Application

Available in manual or fully automatic print and apply, the PAC5 delivers high accuracy label placement every time.

■ Intelligent Operations

Automatic setup, with multiple programmable labels for easy changeovers to different types and sizes. Multi-language touch screen operator panel can be used with the General Data SmartTouch Panel for a complete solution. The PAC5 also offers advanced PLC & I/O, as well as USB, Ethernet, Serial, and WiFi connectivity options.



Product Specifications:

Dimensions: WxDxH	29x18x15.25 (in) 736x457x388 (mm)	Printable Resolution:	Up to 1200x1200 dpi full color
Weight:	95 lbs 43 kg	Air (as needed):	80 psi @ 4 cfm
Voltage:	115 Volts AC 60Hz 8 Amps 220 Volts AC 50Hz 4.0 Amps	Dispense Accuracy:	Up to +/- 1/32" (.8mm)
Label Width:	Up to 4.25" (108 mm) or Up to 8.34" (212 mm)	Label Length:	Up to 12" (178 mm) - Dependent on Tamp Pad
Requirements:	Compressed air, 2-3 CFM, 60 psi	Standard Tamp Pad:	4"x4" (others on request)

Options:	Roll-around or fixed stand	Air-blow conversion
	Conveyor side-mounting bracket	Front tamp configuration
	Label on pad detection	Corner wipe-around configuration
	Smart Touch Panel	Custom programming



More Information

844.643.1129 | www.general-data.com | talktous@general-data.com

©2023 General Data Company, Inc. All rights reserved. Specifications are current at the time of publication; however, they are subject to change without notification. EPSON and ColorWorks are registered trademarks of Seiko Epson Corporation. All other trademarks and registered trademarks are property of General Data Company, Inc., Cincinnati, Ohio, USA.



Smarter Technology. Exceptional Results.

General Data Company, Inc.
4354 Ferguson Road, Cincinnati, OH 45245
844.643.1129

Email: talktous@general-data.com
Web: www.general-data.com

Service:
PH: 800.245.5029
Email: customersupport@general-data.com