

Xerox® B210 Printer and B205/B215 Multifunction Printers



REMARKABLE RELIABILITY MEETS EXTREME ECONOMY.

xerox™

Xerox® B210 Printer and B205/B215 Multifunction Printers

Your ideas never stop. Neither should your printer. Perfect for small work teams or the home office, the Xerox® B210 Printer and B205/B215 Multifunction Printers give you performance and reliability you can count on, day-in and day-out. Because nothing should stand in the way of your next big idea.



PRINT YOUR WAY.

Print securely from your mobile device, laptop or desktop with native AirPrint, Google Cloud Print, Mopria and Android support.

AN INTUITIVE SCREEN FOR INTELLIGENT WORK.

Swipe and tap your way through ultra-simple print, copy and fax functions with a familiar touchscreen experience.*

CUT THE ETHERNET CORD.

Your work is wireless. Now printing can be too. Easily connect to your network and start working.

NO WI-FI? NO PROBLEM.

Wi-Fi Direct® provides a secure connection from your printer to any device. So you can print wirelessly without a router or complicated setup.

PLUG AND PRINT.

Print directly from any flash drive or external hard drive using the front USB port.**

COMPACT PERFORMANCE.

Lightweight enough to stow on a bookshelf. Quiet enough to live in the nursery. But ready to print fast with up to 31 black-and-white ppm Letter/30 black-and-white ppm A4.



*Only available on B215.

**Only available on B205/B215.

Need more than print? We've got you covered with two business-focused multifunction printers that couldn't be easier to use.

B205/B215 HIGHLIGHTS

- Compact, quiet and lightweight to fit perfectly in tight, busy spaces.
- 3.5-inch capacitive touchscreen user interface (UI) gives you smartphone-like functionality.*
- Color scanning helps you create electronic files in a flash. Save files to your network or desktop, or open them in an application.
- Scan directly to USB, email, PC or network.
- Keep your data secure with SNMPv3 and IPv6 network security protocols and Secure Fax Receive, which holds a fax until you log in to retrieve it.



*Only available on B215.



B210 QUICK FACTS

- LED UI
- Built-in Wi-Fi connectivity
- Print up to 31 B&W ppm Letter / 30 B&W ppm A4
- Two-sided printing
- 600 x 600 dpi; 1200 x 1200 dpi enhanced
- WxDxH: 368 x 334.5 x 213.4mm / 14.5 x 13.2 x 8.4 in.
- Weight: 7.56 kg / 16.67 lb.



B205 QUICK FACTS

- 2-line LCD UI
- Built-in Wi-Fi connectivity
- Print up to 31 B&W ppm Letter / 30 B&W ppm A4
- Single-sided printing
- Copy/Print/Scan
- 600 x 600 dpi; 1200 x 1200 dpi enhanced
- WxDxH: 401 x 362 x 365.1mm / 15.8 x 14.3 x 14.4 in.
- Weight: 10.97 kg / 24.18 lb.



B215 QUICK FACTS

- 3.5" capacitive touchscreen UI
- Built-in Wi-Fi connectivity
- Print up to 31 B&W ppm Letter / 30 B&W ppm A4
- Two-sided printing
- Copy/Print/Scan/Fax
- 600 x 600 dpi; 1200 x 1200 dpi enhanced
- WxDxH: 401 x 396.8 x 365.1mm / 15.8 x 15.6 x 14.4 in.
- Weight: 11.45 kg / 25.24 lb.

Xerox® B210 Printer and B205/B215 Multifunction Printers

DEVICE SPECIFICATIONS	XEROX® B210	XEROX® B205	XEROX® B215
Speed	Up to 31 B&W ppm Letter / 30 B&W ppm A4	Up to 31 B&W ppm Letter / 30 B&W ppm A4	Up to 31 B&W ppm Letter / 30 B&W ppm A4
Duty Cycle ¹	Up to 30,000 pages/month	Up to 30,000 pages/month	Up to 30,000 pages/month
Processor	600 MHz	600 MHz	600 MHz
Memory	256 MB	256 MB	256 MB
Connectivity	Hi-Speed USB 2.0, Ethernet 10/100 Base TX (Embedded type) Wireless 802.11.b/g/n	Hi-Speed USB 2.0, Ethernet 10/100 Base TX (Embedded type) Wireless 802.11.b/g/n	Hi-Speed USB 2.0, Ethernet 10/100 Base TX (Embedded type) Wireless 802.11.b/g/n
Copy and Print Resolution	Copy: N/A Print: Up to 1200 dpi (enhanced)	Copy: Up to 600 x 600 dpi; Print: Up to 1200 dpi (enhanced)	Copy: Up to 600 x 600 dpi; Print: Up to 1200 dpi (enhanced)
First-copy-out Time	N/A	As fast as 14 seconds	As fast as 14 seconds
First-print-out Time	As fast as 8.5 seconds	As fast as 8.5 seconds	As fast as 8.5 seconds
Page Description Languages	PCL 5/6, PostScript 3 ² , XPS	PCL 5/6, PostScript 3 ² , XPS	PCL 5/6, PostScript 3 ² , XPS
Print Features	Bi-directional, Real-time Status, Booklet Creation, Poster Printing, Collation, Toner Save, Brightness/Contrast Adjustment, Watermark, Overlay, Skip Blank Pages, Favorites	Bi-directional, Real-time Status, Booklet Creation, Poster Printing, Collation, Toner Save, Brightness/Contrast Adjustment, Watermark, Overlay, Skip Blank Pages, Favorites	Bi-directional, Real-time Status, Booklet Creation, Poster Printing, Collation, Toner Save, Brightness/Contrast Adjustment, Watermark, Overlay, Skip Blank Pages, Favorites
Mobile Printing	Apple AirPrint, Google Cloud Print, Mopria, Xerox® Print Service Plug-in for Android	Apple AirPrint, Google Cloud Print, Mopria, Xerox® Print Service Plug-in for Android	Apple AirPrint, Google Cloud Print, Mopria, Xerox® Print Service Plug-in for Android
Scan³	N/A	Black-and-white and color scanning 1200 x 1200 optical, 4800 x 4800 enhanced ⁵ . Destinations include: Scan to USB, Scan to Email, Scan to Network (SMB, FTP), Scan to PC, Scan to WSD; File formats include: JPG, TIFF (single and multi-page), PDF (single and multi-page)	Black-and-white and color scanning 1200 x 1200 optical, 4800 x 4800 enhanced ⁵ . Destinations include: Scan to USB, Scan to Email, Scan to Network (SMB, FTP), Scan to PC, Scan to WSD; File formats include: JPG, TIFF (single and multi-page), PDF (single and multi-page)
Fax⁴	N/A	N/A	MH/MR/MMR/JBIG Compression, Auto Answer, Auto Redial, Auto Reduction, Broadcast Send, Junk Fax Filter, Fax Address Book, Fax Forward to Fax, Secure Fax Receive, Fax Forward to PC
Security	Automatic, Self-Signed Certificate Creation, Trusted Certificate Authorities, IP Filtering, IP Sec, Disable USB Ports, Software Verification	Automatic, Self-Signed Certificate Creation, Trusted Certificate Authorities, IP Filtering, IP Sec, Disable USB Ports, Software Verification	Automatic, Self-Signed Certificate Creation, Trusted Certificate Authorities, IP Filtering, IP Sec, Disable USB Ports, Software Verification, Secure Fax
Warranty	One-year quick-exchange, earn free service coverage with Xerox eConcierge®	One-year quick-exchange, earn free service coverage with Xerox eConcierge®	One-year quick-exchange, earn free service coverage with Xerox eConcierge®

¹ Maximum volume capacity expected in any one month. Not expected to be sustained on a regular basis; ² PS 3 emulation; ³ Available on B205 and B215 only; ⁴ Available on B215 only; ⁵ 4800 dpi via 3rd party TWAIN compliant software

Device Management

Xerox® CentreWare® Internet Services, Xerox® CentreWare Web, Email alerts, Apple Bonjour®

Print Drivers

Windows® 7, 8, 10, Windows Server® 2008, Server 2008 R2, Server 2012, Server 2012 R2, Server 2016, Server 2019; Max OS® version 10.9, 10.10, 10.11, 10.12, 10.13, 10.14; Red Hat® Enterprise Linux 5, 6, 7; Fedora 15, 16, 17, 18, 19, 20, 21, 22, 23, 24, 25, 26; openSUSE 11.2, 11.4, 12.1, 12.2, 12.3, 13.1, 13.2, 42.1, 15.2; Ubuntu 11.10, 12.04, 12.10, 13.04, 13.10, 14.04, 14.10, 15.04, 15.10, 16.04, 16.10, 17.04, 17.10, 18.04, 18.10; SUSE Linux Enterprise Desktop 10, 11, 12; Debian 6, 7, 8, 9; Linux Mint 15, 16, 17

Media Handling

Automatic Document Feeder: 16 lb to 28 lb Bond/ 60 to 120 gsm; Main Tray: 16 - 43 lb / 60 - 163 gsm; Manual Feed Slot: 16 - 58 lb / 60 - 220 gsm

Media Types

Plain, Heavy weight, Thicker, Light weight, Bond, Colored, Cardstock, Labels, Transparency, Envelope, Thick Envelope, Preprinted, Cotton, Recycled, Archive

Learn more at [xerox.com](http://www.xerox.com).

Certifications

To view the latest list of certifications, go to www.xerox.com/OfficeCertifications.

What Comes in the Box

- Xerox® B205 Multifunction Printer or Xerox® B215 Multifunction Printer or Xerox® B210 Printer
- Print Cartridge (Black: 1,000 page capacity)⁶
- Software and Documentation CD (with User Manual, Quick Install Guide, Safety, Regulatory, Recycling and Print Drivers, and Warranty Statement)
- Installation Guide
- Quick Use Guides
- Power Cable, USB Cable
- Fax Cord (Xerox® B215)

Supplies

Standard Capacity Toner Cartridge – Black: 1,500 pages⁶ 106R04346
High Capacity Toner Cartridge – Black: 3,000 pages⁶ 106R04347
Drum Cartridge: 10,000 pages⁷ 101R00664

⁶ Average standard pages. Declared yield in accordance with ISO/IEC 19752. Yield will vary based on image, area coverage and print mode.

⁷ Approximate pages. Declared yield will vary depending on job run length and media size/orientation and machine speed. For more information, visit <http://www.office.xerox.com/latest/SUPGL-01.PDF>.

Configurations vary by geographical location.