

# TACH-IT®

Ben Clements and Sons, Inc.

*is Entry Level Automation™*

## We Offer Solutions for Productivity.

### Model #Mini-Con L Automated "L" Clip Label Applicator:

- Applies a label or wafer seal from the top to the front (the leading edge) of a package creating a secure and attractive closure.
- Perfect for use in the pharmaceutical, medical, vitamin, supplement markets as well as the packaging of food and other items that need an L-Clip closure to secure the top of the box.
- Can apply a tamper evident seal to the box. Uses wafer seals, labels and security seals up to 1 3/4 inch in diameter.
- Can be used as a table-top unit or can be integrated into full production lines.
- Has 2 variable speed bottom conveyors and a variable speed side belt conveyor for moving the product quickly and securely through the label application head.
- Touch Panel controls includes target counter and 5 memory presets there are also position indicators and etched rails for ease of setup.



#### TACH-IT MODEL # MINI-CON L SPECIFICATIONS\*:

Machine Dimensions:	Length 52" (1,300 mm), Width 34" (850 mm), Height 31" (780 mm)
Shipping Weight:	300 Lbs (137 kgs)
Power:	110 Volt
Label Size:	Max: 1 3/4" (45 mm) x 4" (101 mm) - Min: 3/4" (20 mm) x 3/4" (20 mm)
Maximum Conveyor Speed:	60 ft. (9.3 meters) per minute
Maximum Diameter of Label Roll:	Maximum Dia. Label Roll 11 1/2" (292 mm) on a 3" (76 mm) core

**Ben Clements and Sons, Inc.**

50 Ruta Court, South Hackensack, New Jersey 07606  
Tel: 201-440-5500 or 800-222-5540 Fax: 201-440-1455  
Email: [sales@tach-it.com](mailto:sales@tach-it.com) Web: [www.tach-it.com](http://www.tach-it.com)